Adding Machine Paper Scratch Pad

Uses Standard, 3" Adding Maching Paper.